

Palm One Treo 650

Initial Setup:

1. Select "Enable Local Network Time", to do this use the stylus and touch the box next to this option.
2. Select "Done"
3. Press and hold the red end button, this will power on the phone. (if done correctly Bluegrass should be visible in the upper left hand side of the display.)
4. Type "#*#000000" and press "Dial" on the display. This will bring you to the "Activating your Phone" screen.
5. Select "Edit"
6. You will need to replace the highlighted value, in the "Mobile Number" slot, with the "Ten digit Mobile number". To enter in these values simply select the numbers on the keyboard.
7. Using the stylus, touch the value in the "MIN" slot twice. This will highlight this value and you will be able to type in the "MIN".
8. The slot labeled "home SID" should be 1280, and "home NID" should be 65535 or one "0". This is loaded at the time the phone flashed but double check to insure they are correct. If other data is loaded then the phone will need to be re-flashed.
9. Select "Save"
10. The Treo will prompt "Congratulations! You have successfully programmed your Treo." Select "OK"

Notes:

In an effort to preserve battery life, the Treo 650 will go into a sleep mode. You will need to press the "Red/End" button followed by the "Center" button. To change these settings you will need to go into the PDA mode of the device by the button with the image of a house on it. In the top left hand side of the display, it should display "All". If this is not visible, touch the black down arrow, and select "All". Scroll down and select the "Prefs" icon...Select the "Power" option...in the "Auto-off after:" slot, touch the drop down box and select "3 minutes"...Select "Done".

If you would like to disable the "Keyguard" function, follow the steps above with the exception of selecting the "Power" option. At this point you will need to select "Keyguard"...under the slot labeled "Auto-Keyguard" select the drop down box and select "Disabled"...Select "Done".

You do not have to set up the Voice Mail on the Treo, it is automatically programmed with the *86

To program a different Voice Mail One touch Key

From the Phone screen, press the Menu key.
Select Edit Favorite Button, select type - Speed Dial.
Label - Voicemail
Number - 270-765-3611

Quick Key - I chose V for Voicemail since 1 is already taken with the un-editable *86
Tap more at the bottom right hand side of screen and enter the following - p1234567p#p9999 and check the box that says Dial Extra Digits automatically. This is your 7 digit phone number (1234567) and your voice mail password (9999)
Then tap Ok.

UT Starcom/Audiovox 6600 PPC

Initial Setup:

1. Follow the on screen instructions to "Align Screen".
2. After you have performed the action of aligning up the screen and run through a sample of "Cut and Paste", you will need to select your "Location". This will be the time zone in which the customer resides. (GMT-6 Central US or GMT-5 Eastern US) Once you have selected the time zone press "Next" using the stylus.
3. Once the PPC will prompt you that the "Setup is Complete", tap the screen using the stylus.
4. The PPC will run through its routine setup maintenance.

Programming NAM:

Before starting the NAM settings the phone needs to be on.

1. Touch the "Start" button, to bring down a drop box, and select "Phone" using the stylus. This will bring up the cellular phone feature on the PPC.
2. Select "Tools" in the drop box, select "Activation Wizard" using the stylus. (This will run you through the NAM 1 setup.)
3. The PPC will prompt you "Speak with a Customer Care..." at this point select "Next" using the stylus.
4. The PPC will prompt you "If you have already set..." at this point select "Next" using the stylus.
5. The PPC will display the ESN, in Hex format, in the box below you will need to input "000000". This is the security code to enter the programming mode. (To type in the "000000" using the stylus touch the box until a scroll appears, then touch the Keypad icon in the lower right hand side of the display. This will bring up a keypad on the lower portion of the display that you can input values. By touching the Keypad icon again, the keypad display will be minimized.)
6. After you input the "000000" select "Next".
7. The PPC will display three separate boxes, at the top of the display, in these boxes you will need to enter the "Ten Digit MDN"
8. The PPC will display a fourth box, to the lower portion of the display; this is where you will enter in the "Ten Digit MIN". (It is labeled "MSID" this is just another term for "MIN")
9. Once, you have entered in the MDN and MIN, close out the keyboard by touching the icon again then select "Next".
10. The PPC will prompt you to enter in a "SID", in the box input the value of "1280".
11. After you input "1280" select "Finish", the PPC will prompt you "Are you sure to save these setting?" Click "Yes then "OK".

UT Starcom/Audiovox 6600 PPC

Data Programming:

1. Touch the "Start" button and select "Settings".
2. Select "Connections", this is located on the bottom of the display.
3. Select the "Connections" icon; this is located on the top right hand side of the display.
4. Select "Advanced", this is located on the bottom of the display.
5. Select the "Select Networks" icon; this is located on the top right hand side of the display.
6. Touch the second drop down box. Once the contents of the box are displayed, select "Cdma2000".
7. Select "OK".
8. Select "OK".
9. Select the "Connections" icon; this is located on the top right hand side of the display.
10. Select "Manage existing Connections" under "CDMA2000".
11. Select "Edit", this is located on the bottom of the display.
12. No changes needed on the CDMA1X screen. CDMA1X is in the first box and Cellular Line is in the second.
13. Select "Next".
14. The PPC will display "Enter the number exactly..." in the box enter "#777".
15. Select "Next".

16. The PPC will display "User name" enter is your ten digit mobile number followed by @myblueworks.com.
Example: 2705551234@myblueworks.com
17. The PPC will display "Password" enter in "blue".
18. Leave Domain blank.
19. Select "Finish".
20. Click OK until you return to the main screen.

Voice Mail Programming:

1. Touch the "Start" button and select "Phone".
2. Select "Tools"
3. Select "Options..."
4. The PPC will display "Voicemail" in this box you will need to enter in the voicemail number.
(Example-"2707653611pppp1234567pppp#9999) This is your 7 digit phone number(1234567) and your voice mail password (9999)
5. Touch the "OK" button; this is located at the top right hand side of the display.